

Multimedia Equipment Operations

Jacaranda Hall new smart rooms

Computer Projection

- ▶ Turn on projector using the Epson remote control.
- ▶ Select “*computer 1*” source on the Epson remote control.
- ▶ Connect computer to VGA input on wall plate.
- ▶ Connect computer to data port to use Internet.
- ▶ To play back audio files connect computer to PC audio input on wall plate *and*
Turn on amplifier and select “*PC audio*”. Speaker 1 and speaker 2 must be on.

Video Projection

- ▶ Turn on projector using Epson remote control.
- ▶ Select “*video*” source on the Epson remote control.
- ▶ Turn on DVD/VHS player, load disc and play *or*
load tape and play.
- ▶ Turn on amplifier and select “*video*”. Speaker 1 and speaker 2 must be on.

CD Playback

- ▶ Turn on DVD player, load CD and play.
- ▶ Turn on amplifier and select “*video*”. Speaker 1 and speaker 2 must be on.

University Video Network (UVN)

- ▶ Turn on projector using the Epson remote control.
- ▶ Select “*video*” source on the Epson remote control.
- ▶ Turn on DVD/VHS player and tune to assigned channel.
- ▶ Turn on amplifier and select “*video*” input. Speaker 1 and speaker 2 must be on.
- ▶ Use telephone and remote control instructions to control playback.

VGIS Closed Caption Decoder (works exclusively with VGIS remote control)

- ▶ Press “*menu*” on remote control, on the menu page select [4].
- ▶ To turn captions **ON**, select [2].
- ▶ To turn captions **OFF**, select [1].
- ▶ Press “*menu*” to exit.

**For assistance call Media Equipment Services at x3062
Between 8am and 10pm M-TH and 8am -5pm Fr.
For training call Debbie Hellman at x6363.**

To turn PROJECTOR OFF, press the remote control
power button twice.

PLEASE TURN ALL EQUIPMENT OFF AND LOCK CABINET AFTER USE